


The installation of inner tent

To extend the service life of the tent, please choose a flat place to camp the tent.

1. Unfold the tent on the ground.
2. Set up and connect each pole (including fiberglass poles and steel poles).
3. Insert the assembled poles through the poles' sleeves(as shown in figure A).
4. Insert the 4 steel poles (marked Red) into the joint of four corners of tent (as shown in Figure B).
5. Insert all fiberglass rods into the corresponding connector. (as shown in figure D)
6. Insert one end of the steel pole into the connector and insert the other end into the metal ring corresponding to the four corners of the tent. (as shown in figure E)
7. Tighten the tent and insert the ground nail. (as shown in figure G)



The installation of tent fly

1. Put the tent fly on the tent and use the corresponding Velcro to stick the pole. (as shown in figure H)
2. Insert plastic clip on web strap on tent fly into buckle connector located on web strap at base of leg pole. (as shown in figure I)
3. Please use guyline and ground nail to fix the tent, when it is with the strong wind. (as shown in figure J)

